
CONTENTS



SAFETY INFORMATION

Only one light bulb per socket.

Only suitable for direct mounting on non-combustible surfaces.

Under no circumstances can Blow Fixtures be mounted on normally flammable surfaces.


Suitable for dry, indoor use only.

Maximum ambient temperatures: 25° C

BLOW CEILING MOUNT INSTALLATION

Note: Please contact a licensed electrician. Note: Do not use bulbs that exceed 25 watts.

- 1. Attach large barrel mount (A) to junction box (B) by screwing provided 8-32 screws from insidebarrel to junction box.
- 2. Mark point to attach small barrel mount (C) 28.4 inches from center of large barrel. Attach small barrel to ceiling using a 3" drywall screw or anchor through the center hole (D).
- 2. Attach fixture to barrels using provided screws through mounting discs.
- 3. Connect wires and tuck inside barrels. Thread on ceiling mount caps (E).
- 4. Screw in light bulbs once fixture is secure.



BLOW CEILING MOUNT INSTALLATION

