


## CONTENTS

---

Mini Endless Sconce



Hex Driver - 5/64



Transformer



8-32 Screw (2)




## SAFETY INFORMATION

---

Only suitable for direct mounting on non-combustible surfaces.  
Under no circumstances can Mini Endless Fixtures be mounted on normally flammable surfaces.  
Suitable for dry, indoor use only.  
Maximum ambient temperatures: 25° C

## WALL INSTALLATION | MINI ENDLESS SCONCE

1. Use the provided dimensions to cut a hole in the wall. Note that the center of the junction box is 0.9" above the center of the fixture backplate.



1. Connect the two lead wires between the provided voltage transformer and the junction box wires. Place the transformer into the junction box.

2. Attach the custom crossbar to the junction box using the (2) provided 8-32 Screws.

3. Pull the two power leads from the transformer through the center hole of the crossbar and attach them with the leads from the fixture using the Wago electrical connectors.

4. Once the power leads are connected, push them back through the hole of the crossbar into the junction box.

5. Once the Crossbar is attached to the wall and the main power leads are pushed back into the junction box, lift the fixture and attach the lead wires using the Wago connectors.

6. Feed the leads back through the center hole of the crossbar and fit the sconce onto the crossbar.

