CONTENTS

Valo

| Wago Connector (2)	Wago Connector (2)
(x2) Long 8-32 screw On 240V fixtures only	**(x2) Wood screw** On 240V fixtures only
(x2) Metal screw On 240V fixtures only	**(x2) Toggle anchor** On 240V fixtures only

Bulb

SAFETY INFORMATION

Only one light bulb per socket.
Only suitable for direct mounting on non-combustible surfaces.
Under no circumstances can Valo be mounted on normally flammable surfaces.
Suitable for dry, indoor use only.
Maximum ambient temperatures: 25˚ C

WALL INSTALLATION | VALO

*Note: Please contact a licensed electrician.*

1. Start with unscrewing the canopy nut (A) to release the internal assembly (B) from the canopy (C).

B

C

A

WALL INSTALLATION | VALO

Note: Please contact a licensed electrician.

2. Connect the lead wires from the j-box to the fixture wires with provided 2 port wagos (D).

3. Connect the ground wire to the crossbar using the grounding screw (E).

4. Mount the crossbar (F) onto J-box (G), and secure it with two screws (H).

WALL INSTALLATION | VALO

Note: Please contact a licensed electrician.

5. Raise the canopy (C) over the internal assembly (B), and secure it with canopy nut (A).
   Be sure to tuck all wires inside.

BULB INSTALLATION

Note: Please contact a licensed electrician.

1. Screw in the included LED bulb (A) into the socket (B) in a clockwise direction.

B

A