
















CONTENTS

Updated 18SEPT2019

(x1) Lighting Assembly



(x1) Threaded tube 	(x1) Cover tube 	(x1) Canopy 		(x1) Crossbar assembly 	
		(x6) Glass 	(x6) LED Bulbs 	(x3) Wago Connector 	(x1) Driver 
		(x1) L-Key 	(x2) 8-32 Screw 		
		(x2) Wood screw On 240V fixtures only 	(x2) Long 8-32 screw On 240V fixtures only 	(x2) Metal screw On 240V fixtures only 	(x2) Toggle anchor On 240V fixtures only 

SAFETY INFORMATION

Suitable for damp locations


Maximum ambient temperature: 25°C

CAUTION RISK OF FIRE – MAX 3W TYPE G4 LED self ballasted UL1993/CSAC22.2 no. 1993

NOVA | INSTALLATION


Note: Please contact a licensed electrician for installation. Ensure power is off during installation.

01. Feed the wires (A) from the Lighting assembly (B) through the threaded tube (C) and cover tube (D).
02. Secure the assembly by fastening the threaded tube onto the hub. Tighten the setscrew with the provided L-Key (E).




NOVA | INSTALLATION

3. Unthread the collar (A) on the hangstraight at the crossbar assembly and carefully bring it down to rest at the bottom of the stem. Then bring the canopy (B) down the length of the stem (C) to rest as well. Be careful not to scratch the finish on the stem in this process.



4. Feed the cable through the crossbar assembly. Then thread the crossbar assembly (D) onto the threaded tube (E) to secure the assembly.




NOVA | INSTALLATION

5. Connect the driver (H) to the power source from the ceiling and then carefully arrange the driver and wires into the junction box. Leave the driver output wires accessible for connections in the next step.

Then bring the chandelier assembly (with crossbar assembly threaded onto stem) up to the junction box and secure it in place using two 8-32 screws (I) as shown below. Ground the crossbar as shown below.


240V VERSION: Use the provided Toggle anchors and screws as necessary to secure the fixture to the ceiling.



NOVA | INSTALLATION

6. Make the connections between the driver and the fixture.

Once the required connections are made, the canopy (F) can be brought up flush with the ceiling. Be careful not to pinch any wires or to scratch the finish on the stem. Then bring the collar (E) up and secure the canopy in place.



7. Insert the two leads from the LED bulbs (J) into the sockets (K) as shown below. Then carefully thread the glass diffuser (L) in place.

